Installation Instructions

Descriptions

The luminarie contains a constant-current driver and LED light sources. It works under technical conditions as the product labels indicate.

Technical Parameter

| | | LED Street Light | | | | | |
|----------------------|------------------------------|-----------------------------|-------|------------|---------|--|--|
| Power | 20W | 30W | | 40W | | | |
| Input Voltage | □ 100~240V □ 100~277V □ 220~ | -240V 🗌 120~277V 🗍 277~480V | Other | Frequencey | 50/60Hz | | |
| Power Factor | | 0.95 | | | | | |
| Working Environment | | -40℃~+50℃, 10%~90%RH | | | | | |
| Bolt Torque | | 8Nm | | | | | |
| Mounting Height | | 3~6m | | | | | |
| Mounting Spacing | | 10~21m | | | | | |
| Dimensions | | 395x125x95mm | | | | | |
| Net Weight | 1.8kg | | | | | | |
| Project Area | | 0.050m ² | | | | | |
| Degree of Protection | □ IP54 | □ IP65 □ IP66 □ IP67 □ 0 | Other | | | | |


Notes: The parameters above are typical values subject to tolerance of 10%.

Applications


Factory, schoolyard, garden, park, residential area, courtyard, etc.

Installation and Maintenance

Installation



1. Connect the input wires to L, N, and GND of AC power supply. Make sure it grounded sufficiently.




 Loosen the the screws for fixture mounting. Stick the pole arm into the mounting tube. Fasten up the two screws evenly in a way of multiple interchange instead of one-by-one, making sure of the comliance of torque force. Installation finished.

Installation Instructions

Wiring

| Power Supply End | Earth wire | Neutral wire | Live wire |
|----------------------|---|---------------------------|------------------------------|
| Fixture End | Yellow-green lead | Blue lead | Brown lead |
| | Green lead | White lead | Black lead |
| | | | |
| ution | | | |
| Disconnect or tur | n off power before installa | tion, maintenance and wir | ing. |
| Cable connectior | n must be insulated and w | aterproof. | |
| | th glass cover: the cover in arp edges when it breaks $\Delta t60^{\circ}$ C. | 1 0 | |
| | of this luminaire is not repl ninaire that should be repl | 0 | ource's lifetime comes to ar |
| arning: Danger! El | ectric shock risk! | ^ | |
| (via IEC 60 | 0417-6042 (2011-11) | | |
| or luminaires with g | glass cover: The broke | n cover should be repla | aced. |



The luminaire shall be installed by a qualified electrician and wired in accordance with the latest IEE electrical regulations or the national requirements.



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling

Remarks

- 1. This luminaire uses permanent connection on power supply with flexible cable and wires (60245 IEC57). Sufficient length of cable is reserved for connection to AC power. Protection over the connection join and elimination of tensile force should be ensured to be sufficient.
- 2. This luminaire uses type Z attachment: the external flexible cable or cord of this luminaire cannot be replaced; if the cord is damaged, the luminaire shall be destroyed.
- 3. Wiring: the connection to AC power should be operated on terminal blocks in a wiring box with a degree of protection at least equivalent to the luminaire, and there should be devices to fixate wires.
- 4. The luminaire can be mounted onto ordinary combustible surfaces.