Installation Instructions

Descriptions

The luminaire contains a constant-current driver and LED light sources. It works under technical conditions as the product labels indicate.

Technical Parameter


	LED Street Light			
Power	100W			
Input Voltage	0/60Hz			
Power Factor	0.95			
Working Environment	-40℃~+50℃, 10%~90%RH			
Bolt Torque	17Nm			
Mounting Height	6~15m			
Mounting Spacing	20~45m			
Dimensions	550x205x95mm			
Net Weight	2.7kg			
Project Area	0.113m ²			
Degree of Protection	□ IP54 □ IP65 □ IP66 □ IP67 □Other			

Notes: The parameters above are typical values subject to tolerance of 10%.


Applications

Sub-trunk road, path, parking lot, factory, schoolyard, garden, park, residential area, courtyard, etc.

Installation



1. Connect the input wires to power supply correctly.



2. Mount the luminaire onto the pole. Fasten the M10 screws. Installation finished.

Wiring

Power Supply End	Earth wire	Neutral wire	Live wire
Fixture End	Yellow-green lead	Blue lead	Brown lead
	Green lead	White lead	Black lead

Installation Instructions

Caution





b Cable connection must be insulated and waterproof.

The light source of this luminaire is not replaceable. When the light source's lifetime comes to an end, С it is the whole luminaire that should be replaced.

Warning: Danger! Electric shock risk!

(via IEC 60417-6042 (2011-11))





This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling

Remarks

- 1. This luminaire uses permanent connection on power supply with flexible cable and wires (60245 IEC57). Sufficient length of cable is reserved for connection to AC power. Protection over the connection joint and elimination of tensile force there should be ensured.ufficient.
- 2. This luminaire uses type Z attachment: the external flexible cable or cord of this luminaire cannot be replaced; if the cord is damaged, the luminaire shall be destroyed.
- 3. Wiring: the connection to AC power should be operated on terminal blocks in a wiring box with a degree of protection at least equivalent to the luminaire, and there should be devices to fixate wires.
- 4. The luminaire can be mounted onto ordinary combustible surfaces.